



SW22 Victory “Shadow” C-More Mount Installation Instructions

V1.0

www.tandemkross.com

For more info or support contact info@tandemkross.com

ATTENTION:

Before you begin be certain that the magazine is clear and safe.

PARTS: 1x SW22 Victory “Shadow” C-More Mount

1. Unscrew the screw attaching the factory sight rail and set it aside. This will be used later to affix the “Shadow” Mount to the gun.



2. Slide the sight rail to the right and up off of your SW22 Victory. If the sight rail does not slide easily, wiggle to loosen it.



3. Align the slot in the “Shadow” Mount with the hook on the SW22 Victory. Slide it to the left and align the screw hole. The flat side should be facing up.



4. Tighten the “Shadow” Mount with the factory screw from earlier. Blue Loctite is recommended to keep the screw from loosening during operation.



Helpful Hints:

Loctite works best with clean, oil free surfaces: clean the screw in alcohol and use an alcohol soaked cotton swab to clean the screw hole.

Like any other glue, Loctite needs time to dry in order to be fully effective. It is recommended to wait 24 hours after application before using a firearm.