



“Spartan” Charging Handle for Ruger PC Carbine Installation Instructions

V1.0

www.tandemkross.com

For more info or support contact CustomerService@tandemkross.com

Attention:

Before you begin, be certain that the magazine is removed and the chamber is clear.

You will need a 5/32” allen wrench and/or torque wrench with 5/32” hex bit.

1. Verify that the bolt is all the way forward.



2. Insert original factory cap screw into charging handle.



3. Install the charging handle onto bolt. A small adjustable wrench with tape on the jaws can be used to keep the handle aligned while tightening. Torque cap screw to Ruger specified 65 in*lbs. Check torque after every 1000 rounds.



4. Cycle the bolt to verify that there is no interference between charging handle and receiver slot.

You have successfully completed the installation of your TK “Spartan” Charging handle. Enjoy!

