



Fiber Optic Front Sight for Taurus™ TX22™

V1.0 [www.tandemkross.com](http://www.tandemkross.com)

For more info or support contact

[CustomerService@tandemkross.com](mailto:CustomerService@tandemkross.com)

**Attention:**

**Before you begin, be certain that the firearm is clear and safe.**

*It is recommended to wear safety glasses as some parts are under spring tension.*

*You will need a 5/64 allen wrench or a small flat head screwdriver and the included Torx wrench.*

**Package also contains a Torx head screw.**

1. Using the flat head screwdriver or 5/64 allen wrench, remove stock screw and front sight. The screw comes from the factory with threadlocker applied - penetrating oil, focused heat, or a tap from a punch and hammer may be necessary to break the bond.



2. Position TANDEMKROSS front sight on the barrel and hold it in place as you screw in the included Torx screw with the included Torx wrench. The Torx screw may be too long to use with bull barrel models - either use the stock screw or sand/file down the length of the Torx screw to fit.

