



“Cornerstone” Safety Thumb Ledge for Keltec PMR30, CMR30 and CP33

Installation Instructions

V1.0

www.tandemkross.com

For more info or support contact CustomerService@tandemkross.com

Attention:

Before you begin, be certain that the magazine is removed and the chamber is clear.

You will need a 5/64" or 2mm allen wrench.

1. Place the gun so that the right side is down. Set the safety switch to fire.



2. Use the allen wrench to loosen the screw on the safety lever by turning it counter-clockwise.



3. Remove the old safety lever, keeping in mind where the slots of the safety mechanism are.



